

EXPRESSCLUSTER X for Windows Quick Migration Guide for Microsoft Exchange Server 2010 Migration from a single-node configuration to a two-node mirror disk cluster

Version 1



NEC EXPRESSCLUSTER X 3.x for Windows Quick Migration Guide for Microsoft Exchange Server 2010 Migration from a single-node configuration to a two-node mirror disk cluster

Document Number ECX-Exchange2010- QMG, Version 1, May 2015 Copyright © 2015 NEC Corporation.

Microsoft® and Windows® are registered trademarks of Microsoft Corporation. Other system names, company names, and product names are trademarks and registered trademarks of their respective companies.

Disclaimer

The contents of this document are subject to change without notice. NEC Corporation assumes no responsibility for technical or editorial mistakes in or omissions from this document. To obtain the benefits of the product, it is the customer's responsibility to install and use the product in accordance with this document. The copyright for the contents of this document belongs to NEC Corporation. Copying, altering, or translating this document, in full or in part, without the permission of NEC Corporation, is prohibited.

Contents

	Using	this guide	. 5
	Where	to go for more information	. 6
1		rview	
2	Syst	tem Requirements and Planning	. 8
	2.1	System Requirements	. 8
	2.2	System Planning	. 9
3	Syst	tem Setup Preparation	11
	3.1	Set up the Standby Server (Machine 2)	11
4	EC 2	X Server Installation	11
	4.1	Install EC X on the Primary Server (Machine 1)	11
	4.2	Install EC X on the Standby Server (Machine 2)	12
	4.3	Restart the Primary and Standby Servers (Machines 1 & 2)	12
5	Bas	e Cluster Setup	
	5.1	Install Java Runtime Environment (JRE)	13
	5.2	Start the EC X Cluster Manager	13
	5.3	Create a cluster	
	5.4	Create a failover group	13
	5.5	Create Mirror Disk Resource	
	5.6	Upload the cluster configuration and initialize the cluster	14
6	Prep	paring Servers to Execute Scripts	
	6.1	Set Powershell's Script Execution Policy	
	6.2	Create Copy of RemoteExchange.ps1 and Modify the Copy	
7	Micr	osoft Exchange Server 2010 Cluster Setup	
	7.1	Move the Mailbox Database from Default Location to Data Partition	17
	7.2	Copy and configure failover scripts	
	7.3	Adding Application Resources to Control a Mailbox Database	18
	7.4	Upload the cluster configuration and start the cluster	
8		t Cluster and Verify Functionality	
9		nmon Maintenance Tasks	
	9.1	Start Cluster Manager	
	9.2	Shutdown/Reboot one or all cluster servers	
	9.3	Startup/stop/move failover groups	
	9.4	Isolate a server for maintenance	
	9.5	Return an isolated server to the cluster	
		1 Automatic Recovery	
		2 Manual Recovery	
	9.6	Rebuild a mirror disk	
		A: EC X Server Uninstallation	
A	opendix	B: Example System Planning Worksheet	25

About this Guide

Using this guide

This guide provides a hands-on "Quick Migration" set of instructions to install and configure EXPRESSCLUSTER X (EC X) for Windows with Microsoft Exchange Server 2010 SP3 UR8. The guide assumes users have Microsoft Windows system administration knowledge and skills with experience in installation and configuration of Microsoft Windows operating systems, networks, and Exchange. It is also assumed that the user has a minimal Exchange Server 2010 environment with the Mailbox, Client Access, and Hub Transport Roles on three separate servers. The server with the Mailbox Role will be clustered with EC X on a fourth server.

This guide covers the following topics:

Chapter 1: <u>Overview</u> – describes the general steps of setup procedures.

Chapter 2: <u>System Requirements and Planning</u> – describes the overall system and network requirements, and includes a set of tables for planning the installation and configuration.

Chapter 3: <u>System Setup</u> – describes the configurations required for each system before installing target application.

Chapter 4: <u>EC X Server Installation</u> – describes EC X installation on the Primary and Standby Servers.

Chapter 5: <u>Base Cluster Setup</u> – describes the process of generating a cluster, creating a failover group, and uploading a configuration.

Chapter 6: <u>Preparing Servers to Execute Scripts</u> – describes configuration steps for preparing cluster nodes to execute EC X PowerShell failover scripts.

Chapter 7: <u>Microsoft Exchange Server 2010 Cluster Setup</u> – describes required configuration to enable full cluster functionality.</u>

Chapter 8: <u>Test Cluster and Verify Functionality</u> – describes steps to verify and test the cluster and complete the deployment on a Primary and a Standby Server.

Chapter 9: <u>Common Maintenance Tasks</u> – describes how to perform common maintenance tasks using the EC X Manager.

Where to go for more information

Refer to additional documentation under the "documentation" directory on the EC X distribution CD.

For more information, go to: <u>http://www.nec.com/expresscluster</u>

Other EC X guides are at: http://www.nec.com/expresscluster/en/support/manuals.html


- Getting Started Guide General cluster concepts and overview of EC X functionality.
- Installation and Configuration Guide EC X installation and configuration procedures.
- **Reference Guide** Commands for EC X scripts and maintenance commands to execute from the command prompt.

Contact: info@expresscluster.jp.nec.com

1 Overview

The general procedure to deploy EC X on two servers (referred to as Primary and Standby) with Microsoft Exchange Server 2010, Mailbox role only, consists of the following major steps:

- 1. Perform system planning to determine requirements and specify configuration settings *prior* to the start of actual system installation and configuration.
- 2. Prepare the Standby Server, including OS installation and configuration, and Exchange Server 2010 Mailbox role installation and configuration.
- 3. Install and configure EC X on the Primary and Standby Servers.
- 4. Create and configure the EC X failover group to enable continuous protection and automatic recovery for mailbox database.
- 5. Upload the configuration file and start the cluster to complete deployment in the mirror disk configuration.



2 System Requirements and Planning

2.1 System Requirements

Machine 1: Primary Server (with Exchange Server 2010 Mailbox role) Machine 2: Standby Server (with Exchange Server 2010 Mailbox role) Machine 3: Test Client (a machine with an email client)

	Machine 1 Primary Server	Machine 2 Standby Server	Machine 3 Test Client		
Memory	4GB or more		1GB or more		
Disk	 1 physical disk OS partition: 50GB or more space available (to include the installation of Microsoft Exchange Server 2010) Cluster partition: Partition of 17MB or more, available for EC X Management – the same size for each server system Data partition: Enough partition space to store mailbox database 		OS partition: 50GB or more space available (to include the installation of Microsoft Exchange Server 2010) Cluster partition: Partition of 17MB or more, available for EC X Management – the same size for each server system Data partition: Enough partition space to		1 physical disk with 20GB or more space available
os	Windows Server 200 Enterprise) with the l		Windows 7 or newer		
Software	Java Version 6.0 Update 20 (or later) enabled Web browser Microsoft Exchange Server 2010 SP3 UR8		Java Version 6.0 Update 20 (or later) enabled Web browser		
Network	2 – 100Mbit or faster Ethernet network interface cards		1 – 100Mbit or faster Ethernet network interface card		

2.2 System Planning

Review the requirements from the last section and then fill in the tables of the worksheet below. Refer to <u>Appendix B: Example System Planning Worksheet</u> for an example worksheet. This is useful when creating the cluster later.

Machine 1 Primary Server (with Mailbox role of Exchange Server 2010) Machine 2 Standby Server (with Mailbox role of Exchange Server 2010) Machine 3 Test Client (a machine with an email client)

	-	_				
Machine	Host name	Network	IP Address	Subnet	Default	Preferred
Maonine	noot nume	Connection		Mask	Gateway	DNS Server
1		Public:				
		Interconnect:				
2		Public:				
		Interconnect:				
3						

Table 1: System Network Configuration

Mailbox Database Name:

Floating IP (FIP) address:

Web Management Console FIP: _

Table 2: System OS and Disk Configuration

Machine	OS	Disk 0 (OS Disk)	Disk 1 (Data Disk)
1	Boot Partition: Drive Letter: Size:		Cluster Partition: Drive Letter: Size (>20MB) :
2		Boot Partition: Drive Letter: Size:	* Data Partition: Drive Letter: Size:
3			

* The size must be large enough to store all data, and log files for a given Microsoft Exchange Server 2010 installation to meet current and expected future needs.

Table 3: System Logins and Passwords

Computer/Account	Login	Password
Machine 1 Administrator		
Machine 2 Administrator		
Machine 3 Administrator		
Domain Administrator		

3 System Setup Preparation

3.1 Set up the Standby Server (Machine 2)

- 1. If necessary, install hardware components, OS, and Service Packs identical to the Primary Server (Machine 1).
- 2. Install and configure Exchange Server 2010 with the latest update rollup and only with the Mailbox Role.

4 EC X Server Installation

4.1 Install EC X on the Primary Server (Machine 1)

- 1. Insert the EXPRESSCLUSTER X CD-ROM into a CD-ROM drive on the server.
- 2. In the pop-up window, click **NEC EXPRESSCLUSTER for Windows**.
- 3. Click on **NEC EXPRESSCLUSTER X 3.x for Windows**.
- 4. In the **Welcome** window, click **Next**.
- 5. In the **Choose Destination Location** window, click **Next**.
- 6. In the next window, click **Install**.
- 7. In the Port Number window, if necessary, modify the default port numbers. Click **Next**.
- 8. In the Filter Settings of Shared Disk window, click Next.
- 9. In the **Confirmation** window, click **Yes**.
- 10. In the License Manager window, click Register.
- 11. In the License Registration window, click Register with License Information.
- 12. In the **Product Selection** window, select the **OS** and **Product/Trial** types. For **Product Name**, click **EXPRESSCLUSTER X 3.x for Windows**. Click **Next**.
- 13. In the License Unit Selection window, depending on the type of license, enter the number of CPU or Node Units. Click Next.
- 14. In the License Key Entry window, enter the Serial No. and License Key. Click Next.
- 15. In the License Registration Confirmation window, confirm the information entered is correct. Click Next.
- 16. Click **OK**. If the license registration fails, start again from step 10.
- Repeat steps 10-16 again for the EXPRESSCLUSTER X Replicator 3.x for Windows product license. Select EXPRESSCLUSTER X Replicator 3.x for Windows as the Product Name in step 12.
- 18. In the next window, click **Finish**.
- 19. On the InstallShield Wizard Complete window, click the No, I will restart my computer later option button, and then click Finish.
- 20. In the next window, click **Exit**. Click **Exit**. (Two times total).

4.2 Install EC X on the Standby Server (Machine 2)

Perform all of the steps in Section <u>4.1</u> on the **Standby Server**.

4.3 Restart the Primary and Standby Servers (Machines 1 & 2)

First restart the **Primary Server**, and then restart the **Standby Server**.

5 Base Cluster Setup

5.1 Install Java Runtime Environment (JRE)

Verify JRE Version 6.0 Update20 or newer is installed on a machine to be used for cluster management. Also install on the nodes (Machine1 and Machine2) if they might be used for cluster management. If necessary, install JRE by performing the following steps:

- 1. Run **jre-<build and platform version>.exe** (a compatible JRE distribution is in the jre folder on the EXPRESSCLUSTER CD).
- 2. In the **License Agreement** window, verify the default **Typical setup** option button is selected. Click **Accept**.
- 3. On the Installation Completed window, click Finish.

5.2 Start the EC X Cluster Manager

Start by accessing port 29003 of the **Primary Server** from the Web browser of the cluster management machine, using the Primary Server's IP address. Example: http://10.1.1.1:29003. When the security warning window displays, select the **Always trust content from this publisher** check box. Click **Run**.

5.3 Create a cluster

For all of the steps below, refer to <u>Table 1</u> for the IP addresses and server names.

- 1. When the cluster manager is opened for the first time, there is a pop-up window with three options. Click **Start cluster generation wizard for standard edition**.
- 2. In the new window, type a cluster name. (Example: cluster).
- 3. Type the Management IP address, and click Next.
- 4. In the next window, to add another server to the cluster, click Add.
- 5. Type the hostname or the IP address of the **Standby Server**, and then click **OK**.
- 6. Both servers are now on the list. If the **Primary Server** is not in the top (Master) Server position, then move it up. Click **Next**.
- EC X automatically detects the IP addresses of the servers. Select the network to use the Heartbeat path in the Kernel Mode type. The primary network is for mirroring the data; set Type to Mirror Communication and the MDC as mdc1. Click Next.
- 8. In the NP Resolution window, click Next.

5.4 Create a failover group

For all of the steps below, refer to Table 1 for the IP addresses and server names.

- 1. To add a group, in the **Cluster Generation Wizard**, in the **Group** section, click **Add**.
- In the next window, select failover for group type. Name the group (Example: Exchange_Failover), click Next, and then click Next. (Two times total).
- 3. Select the default options for the Group Attribute Settings, and then click Next.

5.5 Create Mirror Disk Resource

- 1. In the **Group Resources** section of the Cluster generation wizard, to add a resource, click **Add**.
- 2. In the next window, Click **Get License Info** to retrieve the active license for replication.
- 3. To add a mirror disk resource (md), from the drop-down menu, select **mirror disk resource**, and then click **Next**.
- 4. Verify the Follow the default dependency box is selected, and then click Next.
- 5. Verify the default options are correct, and then click **Next**.
- 6. Click **Add** to add the first server.
- 7. Click **Connect** to populate the server partitions.
- 8. Select the data and cluster partitions. Click **OK**.
- 9. Repeat steps 6-8 for the second server.
- 10. Click Finish.
- 11. Click Finish, and then click Next.
- 12. Click Finish.
- 13. Click **Yes** to enable recovery action when an error occurs in a monitor resource.

5.6 Upload the cluster configuration and initialize the cluster

- 1. In the **Cluster Manager** window, click the **File** menu and then **Apply the Configuration File**. Click **OK**. Click **OK**. (Two times total).
- 2. After the upload is complete, change to **Operation Mode**.
- 3. Restart Cluster Manager. Click the Service menu, and then click Restart Manager. Click OK.
- 4. Click the Service menu, and then click Start Cluster. Click OK.
- 5. When the cluster tree displays after a few seconds, in the left pane of the Cluster Manager window, expand the %failover group% section, right click %mirror disk%, and click Details to monitor the disk synchronization progress. Mirror disk copy starts automatically, replicating data from the Primary to the Standby server.

Note

This step may take a while depending on the size of the data in the mirrored disk data partition.

- 6. After the copy completes, in the Mirror Disk Helper window, click Close.
- 7. In the **Cluster Manager** window, all icons in the tree view are now green. Refer to the figure below.

Cluster Manager - Windows Intern	et Explorer			_03
🔄 💿 🗢 😰 http://localhost:29003/		💌 🗟 🍫 🗙 🔎 Bing		، ۹
🔓 Favorites 🛛 🔒 😰 Suggested Sites 🖓	• 😢 Web Slice Gallery •			
		2	🖃 🚔 🔹 Page 👻 Safety	Tesle
Cluster Manager		Ŭ I • DI • I	□ (m) * Page * Safety	• 100IS • 🕜 •
<u>Eile View Service Tool H</u> elp				
🗂 Operation Mode 🛛 🙍 💊	• •			
duster	Cluster Name: cluster	r.		Details
• e primary • e standby		primary	standby	
P Groups P J failover	Group Status			
Y → Innover	failover	Online	Offline	
Monitors	Monitor Status mdnw1	Normal	Normal	
- C mdnw1	mdw1	Normal	Normal	
Type Received Time	Time 👽	Server Name Mod	lule Name Event ID	
one		🐘 📢 Local intranet Protected	d Mode: Off	100% +

- 8. Confirm that the cluster is functioning
 - 8.1 Move the failover group to the **Standby Server** (See Section <u>9.3</u>).
 - 8.2 Move back the failover group to the **Primary Server** (See Section <u>9.3</u>).

Note

This test does not affect server functionality. It verifies that the mirror disks on each server in the cluster are functioning properly.

6 Preparing Servers to Execute Scripts

6.1 Set Powershell's Script Execution Policy

- 1. Launch **PowerShell** on the **Primary Server**.
- 2. Use **Get-ExecutionPolicy** to check the current script execution policy.
- Set the execution policy to RemoteSigned or Unrestricted using Set-ExecutionPolicy in order to run EC failover scripts.

PS> Set-ExecutionPolicy RemoteSigned

4. Repeat this process on the Standby Server.

6.2 Create Copy of RemoteExchange.ps1 and Modify the Copy

- 1. Navigate to the Exchange 'Bin' folder (e.g. C:\Program Files\Microsoft\Exchange Server\V14\Bin) on the Primary Server.
- 2. Copy RemoteExchange.ps1 to the same folder and rename the copy to **RemoteExchange-ECX.ps1**.
- 3. Edit RemoteExchange-ECX.ps1 by adding the line **.\ControlMailboxDatabase.ps1** to the section where the functions are called. Comment out **get-banner** and **get-tip** in this section. Also add the error handling code as shown in the example below.

now actually call the functions

#get-exbanner #get-tip

\$ErrorControlMailboxDatabase = 90

```
.\ControlMailboxDatabase.ps1
$bRet = $?
if ($bRet -eq $False)
{
        exit $ErrorControlMailboxDatabase
}
```

4. Repeat this process on the Standby Server.

7 Microsoft Exchange Server 2010 Cluster Setup


To configure the Microsoft Exchange Server 2010 cluster, move the mailbox database to the data partition and change the path using the Exchange Management Shell on the **Primary Server** (Machine 1). Exchange services are monitored by EC X scripts.

7.1 Move the Mailbox Database from Default Location to Data Partition

- 1. Create a folder (Mailbox Folder) on the Data Partition (example: X:\Mailbox Folder).
- 2. Before moving the Mailbox Database and LogFolderPath, make a backup copy of all files.
- 3. Once the backup is made, click on Start and click on Exchange Management Shell.
- 4. Run the following command at the prompt:

Move-DatabasePath –Identity <MDB name> -EdbFilePath <new path to .edb file> - LogFolderPath <new path to folder>

Example: Move-DatabasePath –Identity "Mailbox01" –EdbFilePath "X:\Mailbox Folder\Mailbox01.edb" –LogFolderPath "X:\Mailbox Folder" Refer to the figure below.



Note: This is a good opportunity to rename the mailbox database from the default name if not done previously.

5. Run the following command at the prompt:

Set-MailboxDatabase –Identity <MDB name> –MountAtStartup \$False

6. To verify the change, run the command (using mailbox name in example above):

Get-MailboxDatabase <MDB name> | FI Name,*Path*,MountAtStartup

7. Run the command if you need to mount the mailbox database:

Mount-Database –Identity <MDB name>

7.2 Copy and configure failover scripts

- 1. Download the script files from NEC web site; http://www.nec.com/en/global/prod/expresscluster/en/support/Setup.html.
- 2. Copy all script files to the EXPRESSCLUSTER bin folder (example. C:\Program Files\EXPRESSCLUSTER\bin) on the **Primary Server**.
- 3. Open **SetEnvironment.bat** with a text editor and change the parameters to match your environment.
- 4. Repeat the previous two steps on the **Standby Server**.

7.3 Adding Application Resources to Control a Mailbox Database

- 1. Start the EC X Cluster Manager.
- 2. In the **Cluster Manager** window, change to **Config Mode**.
- 3. Right-click on the **%failover group%**, and then click **Add Resource** to add the first application resource.
- 4. From the drop down list, select **application resource** for **Type**, and give a name to the resource (example: appli-check-service). Click **Next**.
- 5. Uncheck Follow the default dependency and click Next.
- 6. Click **Next** if the default values are acceptable. Make changes to **Retry Count** or **Failover Threshold** first if necessary.
- 7. Check Non-Resident and set the following parameter for Start Path.
 Start Path : CheckExchangeServices01.bat
 Stop Path : (NULL)
- 8. Click **Tuning** and set **0** for **Normal Return Value** and set a **Timeout** value of at least **3600** for **Start** on the **Parameter** tab (see Note below). Click **OK** and then click **Finish**.

Note

The 1st application resource (example. appli-check-service) uses the following parameters in **SetEnvironment.bat** to wait for all Exchange services to be running. RetryCount : 30

RetryInterval : 60

By default, the application resource waits 1800 (= RetryCount x RetryInterval) seconds for all Exchange services to be running. If any services are not running, the application resource starts them and waits 1800 seconds for them to be running. Services can take up to 3600 seconds to start. **It is recommended to set the Timeout value to 3600 or longer** (= RetryCount x RetryInterval + some buffer).

- 9. Right-click on the **%failover group%**, and then click **Add Resource** to add the second application resource.
- 10. From the drop down list, select **application resource** for **Type**, and give a name to the resource (example: appli-control-AD). Click **Next**.
- 11. Uncheck **Follow the default dependency**. Click the first application resource (example: appli-check-service) and click **Add**. Click **Next**.
- 12. Click **Next** if the default values are acceptable. Make changes to **Retry Count** or **Failover Threshold** first if necessary.
- 13. Check Non-Resident and set the following parameter for Start Path.Start Path: ControlActiveDirectory01.bat <MDB name>Stop Path: (NULL)
- 14. Click Tuning and set 0 for Normal Return Value on the Parameter tab.
- 15. Click the **Start** tab and set the following parameters.
 - Domain : your domain name
 - Account : a user belonging to the Schema Admins group
 - Password : password for the above user
- 16. Click **OK** and then click **Finish**.
- 17. Right-click the mirror disk resource (md) and click **Properties**.
- 18. Uncheck **Follow the default dependency**. Click the second application resource just created (example: appli-control-AD) and click **Add**. Click **OK**.
- 19. Right-click on the **%failover group%**, and then click **Add Resource** to add the third application resource.
- 20. From the drop down list, select **application resource** for **Type**, and give a name to the resource (example: appli-control-DB). Click **Next**.
- 21. Uncheck **Follow the default dependency**. Click the mirror disk resource and click **Add**. Click **Next**.
- 22. Click **Next** if the default values are acceptable. Make changes to **Retry Count** or **Failover Threshold** first if necessary.
- 23. Check **Non-Resident** and set the following parameters for **Start Path** and **Stop Path**.
 - Start Path : ControlMailboxDatabase01.bat <MDB name> Mount
 - Stop Path : ControlMailboxDatabase01.bat <MDB name> Dismount
- 24. Click Tuning and set 0 for Normal Return Value on the Parameter tab.
- 25. Click the **Start** tab and set the following parameters.
 - Domain : your domain name
 - Account : a user belonging to the **Organization Management**¹ group
 - Password : password of the above user

¹ The Organization Management group belongs to **Microsoft Exchange Security Group**.

- 26. Click the **Stop** tab and set the following parameters.
 - Domain : your domain name
 - Account : a user belonging to the **Organization Management** group
 - Password : password of the above user
- 27. Click **OK** and then click **Finish**.
- 28. Click **Entire Dependency** in the right pane and check the dependencies. See example below.

Depth	Resource	Name
0	1 st application resource	appli-check-service
1	2 nd application resource	appli-control-AD
2	Mirror disk resource	md
3	3 rd application resource	appli-control-DB

7.4 Upload the cluster configuration and start the cluster.

1. First dismount the mailbox database using Exchange Management Console or the following command before starting the cluster.

Dismount-Database –Identity <MDB name>

- 2. Then in the **Cluster Manager** window, click the **File** menu, and then **Apply the Configuration File**. Click **OK**. Click **OK**.
- 3. After the upload is complete, change to the **Operation Mode**.
- 4. Restart Cluster Manager. Click the Service menu, and then click Restart Manager. Click OK.
- Right-click on the %failover_group% and select Start. Select the Primary Server to start the group on and click OK. The mailbox database will mount on this server. If the cluster is not running, click the Service menu, and then click Start Cluster. Click OK.

Note

There is no need to make changes to Microsoft Outlook or OWA.

8 Test Cluster and Verify Functionality

 Verify the Primary Server is running with mailbox database mounted and the Standby Server is also running, but with no mailbox database mounted. The status can be checked by using Exchange Management Console or the following command.

Get-MailboxDatabase -Status -Identity <MDB name> | FL –Property Name,Mounted,MountedOnServer

2. With the cluster started on the Primary Server, try accessing the mailbox database from an email client such as Microsoft Outlook or OWA.

Test 1: Move Failover Group to Standby Server

- 1. Move the failover group to the **Standby Server** (refer to <u>9.3</u>). Monitor the failover process in the **Cluster Manager** window. Verify that email clients are still able to connect to the mailbox database.
- 2. Move back the failover group to the **Primary Server** (refer to <u>9.3</u>). Verify that email clients are still able to connect to the mailbox database.

Test 2 (Optional): Force Failover to Standby Server

1. Shutdown the **Primary Server** (refer to <u>9.2</u>). This will initiate a failover to the **Standby Server**. Email clients should still be able to connect to the mailbox database.

9 Common Maintenance Tasks

9.1 Start Cluster Manager

There are two methods to start/access **Cluster Manager** through a supported Java enabled Web browser.

Start Internet Explorer or any other supported Java enabled Web browser.

Method 1: Type the URL with the IP address of an active EC X clustered server; a colon (:); and then the cluster server port number. Example: http://10.1.1.1:29003/ Use *during* or *after* the initial setup.

Method 2: Type the URL with the Management IP which was set up during EC X installation; a colon (:); and then the cluster server port number. Example: http://10.1.1.3:29003/ Use *after* the initial setup and *while* the cluster is running.

9.2 Shutdown/Reboot one or all cluster servers

Start **Cluster Manager** (refer to 9.1) and do the following action.

- Shutdown one server. Right-click the **%machinename%**, and then click **Shutdown**.
- Shutdown all servers Right-click the **%cluster name%**, and then click **Shutdown**.
- Reboot one server
 Right-click the %machinename%, and then click Reboot.
- Reboot all servers
 Right-click the %cluster name%, and then click Reboot.

9.3 Startup/stop/move failover groups

- 1. Start Cluster Manager (refer to <u>9.1</u>).
- 2. Under Groups, right-click %failover group% and then click Start/Stop/Move.
- 3. In the **Confirmation** window, click **OK**.

9.4 Isolate a server for maintenance

- 1. Start Cluster Manager (refer to 9.1).
- 2. In the **Cluster Manager** window, change to **Config Mode**.
- 3. Right-click the %cluster name%, and then select Properties.
- Click the Auto Recovery tab. To manually return the server to the cluster, select Off for the Auto Return option. Otherwise, leave it set to On for automatic recovery when the server is turned back on. Click OK.
- 5. If a change was made, upload the configuration file.
- 6. Shut down the server to isolate for maintenance (refer to <u>9.2</u>). The server is now isolated and ready for maintenance tasks.

9.5 Return an isolated server to the cluster

Refer to 9.4 for setting recovery options.

9.5.1 Automatic Recovery

- 1. Turn the machine back on.
- 2. Recovery starts automatically to return the server to the cluster.

9.5.2 Manual Recovery

- 1. Turn the machine back on and wait until the boot process is complete.
- 2. Start Cluster Manager.
- 3. In the **Cluster Manager** window, right-click the name of the isolated server, and then select **Recover**. The isolated server returns to the cluster.

9.6 Rebuild a mirror disk

- 1. Start Cluster Manager (refer to 9.1).
- 2. In the **Cluster Manager** window, in the left pane, right-click **Servers** and then click **Mirror Disks**.
- 3. In the Mirror Disks window, click the Details button.
- 4. In the next window, click the button below the %machine name% of the machine to copy files from [Primary Server (Machine 1)] and then click the button below the %machine name% of the machine name of the destination server to copy files to [Standby Server (Machine 2)].
- 5. Click the **Execute** button. In the **Confirmation** window, click **OK**.

Appendix A: EC X Server Uninstallation

- 1. In the EC X **Cluster Manager** window of the web browser click the **Service** menu, and then click **Stop Cluster**.
- 2. Close the web browser with **Cluster Manager**.
- 3. Stop all EC X services on the server where the uninstall process will be run. To stop all services, follow the steps below:
 - a. On the Start menu, point to Administrative Tools, and then click Services.
 - b. In the right pane, scroll down and double-click the entry for **EXPRESSCLUSTER**. Click the **Stop** button.
 - c. In the Stop Other Services window, click Yes. Click OK.
 - d. Repeat step 3.b. above for the entry for **EXPRESSCLUSTER EVENT**, and then click **OK**.
- 4. On the Start menu, click Control Panel. Click Uninstall a program.
- 5. In the Uninstall or change a program window, under the list of Currently installed programs, click NEC EXPRESSCLUSTER Server. Click Uninstall.
- 6. To start the uninstall process, in the **Confirmation** window, click **Yes**.
- 7. In the next window, click **Yes** to reset the registry settings to disable the media sense functions of TCP/IP disconnect detection.
- 8. In the first Install Wizard Complete window, click Finish.
- 9. On the next **Install Wizard Complete** window, select the **Yes**, **I want to restart my computer now** option button. Click **Finish**. This completes the uninstall process for an individual server system.

Note

To uninstall an EC X Server, you must be logged on as an administrator or have an account with administrator privileges.

After the installation is complete, if any shared disks are in use, unplug all disk cables connected to the servers.

Appendix B: Example System Planning Worksheet

Machine 1 Primary Server (Exchange Server 2010 with Mailbox Role) Machine 2 Standby Server (Exchange Server 2010 with Mailbox Role) Machine 3 Test Client (a machine with an email client)

Machine	Host name	Network Connection	IP Address	Subnet Mask	Default Gateway	Preferred DNS Server
1	Primary	Public Interconnect	10.1.1.1 192.168.1.1	255.255.255.0 255.255.255.0	10.1.1.5	10.1.1.5
2	Standby	Public Interconnect	10.1.1.2 192.168.1.2	255.255.255.0 255.255.255.0	10.1.1.5	10.1.1.5
3	Test Client	Public	10.1.1.6	255.255.255.0	10.1.1.5	10.1.1.5

Table 1: System Network Interfaces

Table 2: System OS and Disks

Machine	OS	Disk 0 (OS Disk)	Disk 1 (Data Disk)
1	Win Server 2008 R2 Std. Ed. or later	Boot Partition: Drive Letter: C Size: 75GB	* Cluster Partition: Drive Letter: W Size: 24MB
2	Win Server 2008 R2 Std. Ed. or later	Boot Partition: Drive Letter: C Size: 75GB	Data Partition: Drive Letter: X Size: 50GB
3	Win 7 or later	C: 20GB	

* Must be a raw partition and larger than 17MB.

Mailbox Database Name: Mailbox01

Floating IP (FIP) address:

```
Web Management Console FIP: <u>10.1.1.3</u>
```

Table 3: System Logins and Passwords

Computer/Account	Login	Password
Machine 1 Administrator	Administrator	admin1234
Machine 2 Administrator	Administrator	admin1234